

R1230RF-01

PLEASE READ INSTRUCTION BEFORE COMMENCING INSTALLATION AND RETAIN FOR FUTURE REFERENCES. ! Electrical products can cause death or injury, or damage to property. If in any doubt about the installation or use of this product, consult a competent electrician. Note: Product technical information and specification may change over time without prior notification. For the latest technical information please visit our web site www.ledgrouprobust.com or www.ledgrouprobust.com.au or ideal.co.nz

Installation diagram;

1. Ensure mains supply is switched off before commencing work.
2. Before cutting, ensure that the cut-out does not impinge on joists, pipe work, cables or other building services
3. Mark cut-out as per template and then remove from the ceiling
3. Insert frame in the cut-out. Align retention clips with slots on the side, insert screws and push down onto plasterboard.
Ensure screws are tight and the frame is secure
4. Connect driver. Offer panel up to frame and manoeuvre into final position similar to standard ceiling tile

